

Übersetzungstabelle für den TRF 415MR/MSXX/TA05/R/MS

HZ	96	97	98	99	100	101	102	103	104	105
Ritzel										
25	8.64	8.73	8.82	8.91	9.00	9.09	9.18	9.27	9.36	9.45
26	8.31	8.39	8.48	8.57	8.65	8.74	8.83	8.91	9.00	9.09
27	8.00	8.08	8.17	8.25	8.33	8.42	8.50	8.58	8.67	8.75
28	7.71	7.79	7.88	7.96	8.04	8.12	8.20	8.28	8.36	8.44
29	7.45	7.53	7.60	7.68	7.76	7.84	7.91	7.99	8.07	8.15
30	7.20	7.28	7.35	7.43	7.50	7.58	7.65	7.73	7.80	7.88
31	6.97	7.04	7.11	7.19	7.26	7.33	7.40	7.48	7.55	7.62
32	6.75	6.82	6.89	6.96	7.03	7.10	7.17	7.24	7.31	7.38
33	6.55	6.61	6.68	6.75	6.82	6.89	6.95	7.02	7.09	7.16
34	6.35	6.42	6.49	6.55	6.62	6.68	6.75	6.82	6.88	6.95
35	6.17	6.24	6.30	6.36	6.43	6.49	6.56	6.62	6.69	6.75
36	6.00	6.06	6.13	6.19	6.25	6.31	6.38	6.44	6.50	6.56
37	5.84	5.90	5.96	6.02	6.08	6.14	6.20	6.26	6.32	6.39
38	5.68	5.74	5.80	5.86	5.92	5.98	6.04	6.10	6.16	6.22
39	5.54	5.60	5.65	5.71	5.77	5.83	5.88	5.94	6.00	6.06
40	5.40	5.46	5.51	5.57	5.63	5.68	5.74	5.79	5.85	5.91
41	5.27	5.32	5.38	5.43	5.49	5.54	5.60	5.65	5.71	5.76
42	5.14	5.20	5.25	5.30	5.36	5.41	5.46	5.52	5.57	5.63
43	5.02	5.08	5.13	5.18	5.23	5.28	5.34	5.39	5.44	5.49
44	4.91	4.96	5.01	5.06	5.11	5.16	5.22	5.27	5.32	5.37
45	4.80	4.85	4.90	4.95	5.00	5.05	5.10	5.15	5.20	5.25
46	4.70	4.74	4.79	4.84	4.89	4.94	4.99	5.04	5.09	5.14
47	4.60	4.64	4.69	4.74	4.79	4.84	4.88	4.93	4.98	5.03
48	4.50	4.55	4.59	4.64	4.69	4.73	4.78	4.83	4.88	4.92

Die Interne Untersetzung des TRF 415MR/MSXX/TA05/R/MS ist

2.25

Untersetzung = $\frac{\text{HZ}}{\text{Ritzel}} \times 2.25 : 1$